



During configuration, get as close as possible to your internet box!

1

Install the Gowind application on your phone, tablet or computer

- **ANDROID** \Rightarrow in the playstore, find and install the GOWIND application
- **IPHONE & IPAD** \Rightarrow SAFARI and enter the address funapp.gowind.fr
- **ORDINATEUR** \Rightarrow (Chrome, Firefox, ...) and enter the address funapp.gowind.fr

If you haven't already, register.

2

Connect your Fungir Mobile



WAIT

1 or 2 minutes



3

When the FunGir Mobile cannot find an INTERNET network, it turns into a WiFi access point.

On your smartphone or tablet, go to "Settings" then "Wi-Fi and Internet"

Look for the "MaFufuMobile" wifi network

1 - Click on the network "MaFufuMobile"



2 - Click on the notification that appears "Connect to the Wi-Fi network"

4

The configuration page of your Fungir Mobile launches

1 - Select the name of your WIFI network from the list

2 - Enter your WIFI password

Be careful not to confuse similar characters like the letter l (letter) or I (india) you can try by replacing the l (L with the i). Likewise, an uppercase "o" may look like zero.



Obligatory:
a 2.4 Ghz WIFI network with a password

3 - Validate



5

Your Fungir Mobile restarts and connects to INTERNET via your WIFI network



WAIT

20 secondes



if this screen back to step 2



6

Launch the GOWIND application

- Click on menu (☰) at the top left and select **Dashboard**
- In the **Dashboard** click on **ACTIVATE A PRODUCT GOWIND**
- Click on

IF

OR

AND

